


profichip NOTOS

I/O Backplane Controller for High-speed Remote I/O

Технические характеристики



По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Россия (495)268-04-70


Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Киргизия (996)312-96-26-47

Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Казахстан (7172)727-132

Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Main Features

- Pin- and function-compatible with existing SliceBus® technology and SNAP+ ASIC
- Integrated LVDS termination resistor
- Asynchronous, serial data transmission with 192 MBit/s over Point to Point LVDS physic
- Many improved features over SNAP+ (see below in specific segments)



The SliceBus 2.0 technology was created to deliver many additional functionalities, in a price sensitive small frame.

Basic SliceBus Information

- Up to 64 slave (node) stations
- Additional alarm line for initialization and asynchronous event communications from node to Master
- Full system detection from SliceBus Master without external information on module configuration

Error Detection Mechanism

- CRC code with Hamming distance 4 for every telegram (all 3-bit errors are detected)
- Watchdog function inside every node for SliceBus Master observation
- "Auto shutdown" in case of SliceBus Master malfunction
- Retry statistic for early detection of possible transmission issues

Time Synchronisation

- Synchronized nanosecond clock for each node
- Option for clock synchronization from SliceBus Master to SliceBus Master via different protocols (PROFIBUS® DP-V2, PROFINET®, EtherCAT®, etc.)

Technological Functions in NOTOS


- Standard I/O function: 8 digital I/O or up to 32 I/O with shift register
- Integrated digital input filter function
- Asynchronous event signaling with nanosecond time stamping for advanced nodes
- Two advanced counters with AB oversampling, latch, reset, output, hysteresis, compare value, repetitive/endless counting and additional time stamp information
- SSI function with time stamp information (speed calculations: counter difference/time)
- Pulse width modulation with 20 ns resolution
- Frequency measurement mode
- Maximum counting frequency of 24 MHz
- Special digital I/O time stamp nodes (ETS: Edge Time Stamp System) for input edge and output control with nanosecond time (independent from fieldbus cycle!)

SPI Interface in NOTOS for Analog I/O / Safety / Serial CP with External MCU

- 80-Mbit/s SPI interface for external microcontroller
- Up to 128 byte In / 128 byte Out data for external microcontroller
- Alarm function and watchdog function
- 3 additional synchronization interrupt outputs
- Channel for extended data exchange
- Extended diagnostic dataset for SPI Master

Mechanical and Electrical Specifications NOTOS

- I/O voltage: 3.3V, typ. 10 mA;
- Core voltage: 1,2V, typ. 22 mA
- LQFP 48 package, 9.0mm², 0,5 mm pitch



По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Россия (495)268-04-70

Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Киргизия (996)312-96-26-47

Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Казахстан (7172)727-132

Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93